





What is the	The reduction of horizontal distances to grid distances is a two-step process:						
difference between	The reduction of horizontal distances to grid distances is a two-step process.						
grid scale factor, elevation scale factor	1.) Reduction from horizontal distance to ellipsoidal distance using the Elevation Scale Factor (ESF)						
and combined scale factor?	Elevation Scale Factor (approx.)						
	Elevation Scale Factor (approx.) ellipsoid distance = horizontal distance * $\left(\frac{R}{R+h}\right)$ $R = radius of Earth,$ h = ellipsoid height,						
	2.) Reduction from ellipsoidal distance to grid distance using the Grid Scale Factor (GSF)						
	grid distance = ellipsoid distance * grid scale factor						
	Often these scale factors are combined in what is known as a Combined Scale Factor (CSF) which allows grid distance to be calculated from ground distance in one step						
	Grid distance = ground distance * combined scale factor						
	CSF = ESF x GSF						
	It can be seen from the formula for calculating ellipsoid distance that unless there is significant ellipsoidal height, the elevation scale factor is very close to 1. For this reason, the GSF is often used as a close approximation of the CSF. It is up to the user to determine if the ESF can be neglected. In Nova Scotia, a typical ellipsoidal height is -20 m. The table below illustrates the impact of ellipsoidal height on the elevation scale factor and also the impact that this has on a 1000.000 m horizontal distance reduction.						





h (m)	ESF	Ellipsoidal Distance based on 1000.000 m Horizontal Distance	Impact of Neglecting ESF (m)
10000	0.998435	998.435	1.565
1000	0.999843	999.843	0.157
100	0.999984	999.984	0.016
10	0.999998	999.998	0.002
	N Sea Elli	Horizontal distance	






What is a point scale factor and line scale factor?	scale factor for a p	articular distance	o the grid scale factor at a specified location or point. A line scale factor refers to a calculated grid e between two points. There are different methods of calculating a grid scale factor depending on ed in the table below.
		Distance	Methodology
		< 1 km	Use point scale factor for any point along the measured line
		< 4 km	Use average point scale factor
		>= 4 km	Use Simpson 1/6 Rule
Where do I find the value of a scale factor?			r can be found in the Full Station Report for NSCMs in the NSCRS Viewer. For NSHPN monuments, ablished in the Full Station Report.





Horizontal Data					
Horizontal Reference Frame:	NAD83 (CSRS) 2010.0 V	v			
MTM UTM Geographic	Cartesian				
Real Zone 5					
Northing	Easting				
4921952.971	2544500	)5.487			
Northing (Standard Deviation	) Easting	(Standard Deviation)			
0.0000	0.0000	0.0000			
Semi Major Axis A	Semi Mi	Semi Minor Axis B			
0.0000	0.0000				
Orientation	Converg	jence (decimal degrees)			
0.000000	0.4836				
Scale Factor	Combine	ed Scale Factor			
0.999937	0.99991	8			
Coordinate Status	Adjustment ID	Coordinate Date (YTTYMMDI			
Adopted (Published) Values	NAD831997_V1p0_AF	2014-09-11			








COORDINATE

REFERENCING








GeoNOVA







GeoNOVA





